

Touch Screen Silicone Seal for Platinum 2.0

Silicone Application Procedure

Purpose



A guideline to add additional sealing to the Platinum 2.0 touch screen.




Safety

- Protective glasses
- Gloves
- Other measures as required by the site

Tools Required:

- Clear RTV Silicone
- Caulking Gun
- Low Adhesive Tape (Painters Tape)
- Clean Cloth

Step (Picture)	Step (Instructions)
<p>Step 1</p> 	<p>Ensure the console is turned off. Clean and dry around the edges of the touch screen where the silicone is to be applied.</p>
<p>Step 2</p> 	<p>Apply the painter's tape around the perimeter of the touch screen leaving 0.125" (3 Pmm) of the touchscreen edges exposed.</p>

Step (Picture)	Step (Instructions)
<p>Step 3</p> 	<p>Using the caulking gun and Clear RTV Silicone, apply a uniform strip of silicone around the perimeter of the touch screen.</p>
<p>Step 4</p> 	<p>Use your finger to smooth the silicone along the perimeter. Inspect the silicone to ensure full coverage. Clean silicone residue with a clean cloth.</p>
<p>Step 5</p> 	<p>Once the silicone has dried, carefully peel the painter's tape off the touch screen.</p>